ENERMAX

EB208U3

USER'S MANUAL

Aluminum 2.5" HDD Enclosure

www.enermax.com / forum.enermax.com

"Brick" EB208U3 HDD Enclosure

A. Package Contents

- "Brick" EB208U3 HDD Enclosure
- USB 3.0 cable
- Tool package
  (Screwdriver*1+Screw for aluminum body*3+Screw for HDD and the PCB board*5)
- User's manual
- Carry Bag

B. Minimum System Requirements

1. Windows 2000/XP/Vista/7
2. Mac OS 9.x (Apple USB support 1.3.5 and greater) and Mac OS 10.1, 10.2, 10.3, and 10.4
3. Computer with USB 3.0, 2.0 or 1.1 interface
4. PC: Intel Pentium 233MHz-compatible processor or greater
5. Mac: G3 processor or greater

*USB 3.0 was not available for Mac OS at the time this manual was written.

"Brick" EB208U3 HDD Enclosure

C. Hardware Installation

1. Remove the HDD tray
2. Connect the SATA HDD to the SATA connectors on the PCBA.

* To make sure the HDD is firmly connected to the PCB, please screw the HDD and the PCB board together.

3. Slide the tray back to the aluminum housing
4. Screw the HDD tray and the aluminum housing with two screws enclosed

D. LED Indicator

- Power : Blue
- Access (Read/Write): Purple

E. Using your EB208U3

Introduction

- Please make sure you format the HDD before the first time use.

- Unplug Procedure on a PC (Microsoft Windows)*
  1. Click on the taskbar icon for the external hardware
  2. Choose the external HDD and confirm to remove it

- Unplug Procedure on a Macintosh (Apple Mac OS)*
  1. Drag the external HDD icon into the trash bin
  2. Turn off your device

*To safely remove your drive and prevent data loss, always follow the unplug procedure. If not, error messages might show up.

F. Q & A

Question:

I could see the icon at the right down comer on the screen, but I still couldn't find my external HDD.

Answer:

a. Please make sure your HDD has been installed correctly.
b. Please make sure your HDD has been set in "Master" position or factory default.
c. Please make sure your HDD has been formatted.

© Copyright 2011 Enermax Technology Corporation. All Rights Reserved.

The information contained in this manual is believed to be accurate and reliable.
Enermax Technology Corporation assumes no responsibility for any errors contained in this manual.
Enermax Technology Corporation reserves the right to make changes in the specifications and/or design of this product without prior notice.
The diagrams contained in this manual may also not fully represent the product that you are using and are there for illustration purposes only.
All mentioned company and product names are trademarks or registered trademarks of their respectable owners.

"Brick" EB208U3 HDD Enclosure

Instrukcja obs.ugi

A. Minimalne wymagania systemowe

1. Windows 2000/XP/Vista/7
2. Mac OS 9.x (Apple USB od wersji 1.3.5) oraz Mac OS 10.1, 10.2, 10.3 lub 10.4
3. Komputer z interfejsem USB 3.0, 2.0 albo 1.1
4. PC: procesor Intel Pentium 233MHz lub lepszy
5. Mac: procesor G3 lub lepszy
6. Minimalnie 32MB pami.ci RAM

B. Instrukcja monta.u dysku twardego

Patrz grafika na stronie 2.

C. Instrukcja u.ytkowania

a. Formatowanie

• Przed pierwszym użyciem należy sformatować dysk twardy. Uwaga: Formatowanie jest operacją nieodwracalną i dane nie mogą zostać odzyskane.

b. Wyświetlacz statusu

• Power: niebieski LED

• Transfer danych (Read/Write): fioletowy LED

"Brick" EB208U3 HDD Enclosure

c. Odłączanie obudowy

• Od komputera PC (Microsoft Windows)*:

1. Kliknij ikonę „Bezpieczne usuwanie sprzętu" w pasku zadań.
2. Wybierz odpowiedni zewnętrzny dysk twardy a następnie kliknij " Bezpiecznie usuń".

• Od komputera Macintosh (Apple Mac OS)*:

1. Przeciągnij ikonę "zewnętrznego dysku twardego" do kosza.
2. Odłącz obudowę od komputera.

*Aby uniknąć uszkodzenia urządzenia lub utraty danych, przy odłączeniu obudowy od komputera należy zawsze przestrzegać procedury podanej powyżej.

D. FAQ (Pytanie i odpowiedzi)

Pytanie:

Pojawia się ikona w prawym dolnym rogu ekranu, ale nadal nie mogę znaleźć zewnętrznego dysku twardego.

Odpowiedź:

a. Proszę upewnić się, że dysk został poprawnie zainstalowany.

b. Proszę sprawdzić, czy dysk twardy jest ustawiony jako "Master" lub w **ustawieniu fabrycznym.**

c. Proszę upewnić się, że dysk twardy został sformatowany przed pierwszym użyciem.